

MAXTER PLUS		BUSH	001, 003, 004, 006, 021, 070, 142, 225, 226	ERISSON	001, 009, 052, 148, 164, 182, 190, 194, 202, 242, 243	HITACHI	001, 003, 004, 010, 013, 014, 018, 019, 024, 036, 046, 057, 060, 063, 069, 074, 079, 082, 093, 105, 122, 164, 198, 240, 241	LOEWE	001, 002, 016, 022, 028, 047, 088	
Spis kodów odbiorników TV		CAMBRIDGE	189	ESC	001			LOGIC	037, 080	
		CANTON	040	ESTEL	021			LOGIK	037, 080	
Marka	Kod	CAPSONIC	049				HITSU	040	LOVE	073
A.R.SYSTEM	028, 073	CARENA	179	ETRON	004, 013		HORYZONT	001, 021, 089	LUKS	049
ADMIRAL	003, 013, 016, 034, 131	CASIO	001, 116	EUROCOM	021		HOSHAI	040, 084	LUMA	003, 004, 010, 034, 035
ADYSON	014, 063, 145	CBM	006	EUROFEEL	014		HUIJIA	164	LUMATRON	001, 034
AGASHI	001, 013	CELINT	004	EUROMAN	001, 014, 068, 140		HYPER	001, 003, 004, 008, 013, 014, 021, 040, 049, 063, 068, 070, 084	LUXOR	003, 004, 006, 010, 014, 024, 026, 039, 042, 051, 060, 077, 079, 089, 111, 122
AIKO	040	CENTURY	008, 016	EUROMANN	014, 068		HYPSON	001, 013, 021, 049, 073, 185	M.D.C.	001
AIOSTAY	013, 014, 021, 062	CGE	001, 003, 006, 008, 012, 013, 021, 038, 052, 131	EUROPHON	008, 014, 021, 023, 028, 091, 134, 158		HYUNDAI-LUXTRONIC	201	M.ELECTRONIC	001, 002, 004, 008, 013, 024, 033, 039, 042, 047, 050, 051, 054, 061, 062, 111, 122
AIWA	007, 162, 213, 232	CGM	001, 013, 038, 040, 049, 068, 070, 084	EUROPHONE	003		IBERVISAO	003, 021		
AKAI	001, 002, 003, 004, 009, 011, 013, 014, 021, 024, 026, 030, 040, 043, 049, 051, 056, 061, 070, 148, 014	CHANGHONG	001, 013, 026, 030, 049, 053, 164, 191, 213, 215, 248, 249, 251, 252, 260, 265	EUROSTAR	029, 039		ICE	001, 008, 013, 014, 040, 049, 070	MACTECH	001, 040, 049
AKI		CIATE	016	EVEREST	001		ICS	013	MAGNADYNE	001, 003, 004, 008, 013, 016, 021, 023, 028, 029, 052
AKIRA	001, 070, 190, 194, 195, 202, 214	CIE	001, 013, 040, 061, 065, 078	EXPERT	003, 043, 044		IEG	014	MAGNAFON	001, 004, 006, 008, 013, 014, 023, 028, 029, 052, 062, 077, 134
AKURA	001, 013, 038, 040, 049, 161, 181	CLARITRONIC	038	FAGOR	021		IMPERIAL	001, 003, 006, 008, 012, 021, 038, 049, 052, 063, 131		
ALBA	001, 021, 040, 052, 058, 065, 070	CLARIVOX	001, 006, 008, 016, 021, 028, 044, 049, 062, 073, 106	FENNER	001, 013, 061, 084		INCOBE	013, 014	MAGNASONIC	001
ALBRAL	001, 008, 021, 023, 028, 049, 073, 158	CLATRONIC	118, 143, 001, 006, 008, 013, 014, 017, 021, 023, 038, 040, 049, 052, 070, 084	FERGUSON	103		INDESIT	055	MAGNUM	052, 192
ALHORI	014	CLAYTON	021	FIDELIS	001, 013, 014, 063		INGELEN	003	MANESTH	001, 003, 014, 017, 021, 030, 058
ALLORGAN	004, 014, 035	COFADEL	011, 018, 019, 031, 046	FIJITSU GENERAL	004, 008, 014, 035, 040		INNO HIT	001, 008, 013, 014, 016, 020, 023, 028, 029, 040, 056, 063, 070, 074, 077, 084	MANHATTAN	003, 052
ALLSTAR	001	COLORLUX	016	FILMET	009		INT	049	MARSHALL	017
AMPLIVISION	014, 073	COLORMATT	016	FILSAI	013, 014		INTERBURG	013	MARECH	013, 040
AMSTRAD	001, 013, 034, 040, 049, 070, 078, 129, 162	COLORTRON	016	FINLANDIA	003, 004, 005, 006, 021, 026, 042, 111		INTERBUY	008, 049, 145	MASCOM	001, 051, 192
AMWAY	001	COMET	001	FINLUX	001, 004, 006, 008, 009, 013, 014, 021, 023, 024, 026, 028, 029, 039, 042, 047, 051, 052, 054, 056, 062, 108, 111, 122, 186, 227		INTERCORD	050	MASCOT	008
ANEX	001	CONCORDE	013	FIRST	237		INTERDISCOUNT	001, 005, 007, 011, 019	MATCH	013
ANGLO	008, 049	CONDOR	001, 006, 013, 017, 023, 038, 049, 052, 054	FIRST LINE	001, 003, 004, 008, 009, 013, 014, 017, 021, 034, 056, 061, 073, 134		INTERFUNK	001, 003, 004, 006, 008, 009, 010, 011, 015, 016, 020, 022, 038, 045, 048, 052, 102	MATSUI	001, 002, 003, 004, 010, 013, 014, 021, 030, 037, 058, 070, 078, 119, 177
ANITECH	001, 006, 013, 017, 023, 049, 063, 084, 145	CONIC	063	FISHER	004, 014, 016, 026, 029, 036, 038, 047, 050, 090, 096, 116, 157		INTERVISION	001, 003, 008, 014, 021, 023, 038, 049, 087, 145	MAXELL	013, 063, 084
ANSONIC	001, 008, 013, 038, 049	CONTEC	013, 014, 036, 065	FLINT	001		IRC	187	MAXIMAL	004
ANTECNO	040	CONTINENTAL	001, 119	FORMENTI	001, 003, 006, 012, 013, 014, 016, 017, 021, 023, 028, 029, 049, 078, 087, 114, 158		IRRADIO	001, 006, 008, 013, 021, 040, 049, 063, 068, 070, 077, 087, 136	MAXON	013
ARC EN CIEL	011, 018, 021, 031	EDISON	005, 010, 011, 018, 019, 028, 031, 033, 046, 113, 135	FORTESS	016		ISKRA	014, 021, 023, 028, 068	MAXWELL	001, 023, 028
ARISTONA	001	COSMEL	001, 013, 143	FRABA	001		ITC	003, 014, 021	MEDION	001, 009
ART TECH	001, 013, 056, 084	COSMOS	001	FRANTECH	008, 013, 014, 021, 049, 063, 078		ITL	013	MEMOREX	049
ARTHUR MARTIN	003	CREATIVE	002	FUJI	084		ITS	013, 014, 040, 049, 070	MEMPHIS	143
ASA	001, 003, 016, 024, 039, 042, 047, 062, 108, 111	CROSLLEY	006, 008, 012, 016, 029	FUJITECH	001		ITV	001	MERRIT	003
ASBERG	001, 006, 008, 023, 052	CROWN	001, 006, 013, 021, 023, 030, 038, 040, 049, 052, 069, 119, 140	FUJITSU	004, 014, 023, 035, 040, 043, 063, 083		JET POINT	001	METZ	001, 002, 016, 022, 045, 067, 081, 099, 100, 109
ASORA	013	CRYSTAL	008, 014, 040	FUNAI	013, 049, 065, 129, 151, 164		JINXING	001, 009, 013, 026, 030, 040, 049, 053, 076, 105, 148, 183, 253	MICA	040
ASTRA	001, 013, 063, 070, 190, 199	CS ELECTRONICS	089	GALAXI(S)	001, 006, 008, 023, 038, 052, 062		JOHNSON	014	MICRON	014
ASTRO SOUND	001, 003, 008, 023, 073	CTV	001, 052, 058, 160	GALERIA	013		JVC	001, 011, 019, 036, 057, 066, 070, 097, 120, 180, 184, 247	MINATO	120
ASUKA	017, 021, 040	CYMATIC	003, 014, 021, 028	GBC	001, 003, 008, 013, 021, 028, 029, 036, 040, 056, 061, 070, 084		KABEL	058	MINERVA	002, 006
ATLANTIC	001, 017, 035, 036, 043	D VISION	001	GEANT CASONIO	003		KAIDO	021	MINOKA	049
ATORO	013	DAEWOO	001, 008, 009, 013, 014, 040, 056, 061, 120, 141, 166, 234	GEER	003, 004		KAISER	001, 004	MISTRAL	075
AUCHAN	003	DAINICHI	014	GEC	001, 003, 004, 006, 010, 014, 028, 036, 056, 057, 074, 102		KAISUI	001, 013, 014, 040, 049, 052, 084	MITSUBISHI	001, 002, 004, 009, 013, 016, 022, 036, 037, 053, 125
AUDIOSONIC	001, 008, 013, 014, 021, 023, 028, 036, 038, 040, 049, 061, 068, 084, 098, 143	DANSAI	049, 063, 156	GELOSO	003, 008, 013, 021, 028, 029, 040, 061		KAMASONIC	014	MITSUMI GENERAL	003
AUDIOSTAR	013, 040	DAWA	001	GENERAL CORP.	004, 014, 035, 036, 043		KAMBROOK	001, 014, 049, 087	MIVAR	006, 014, 028, 072, 077, 104, 124, 165
AUDIOTON	008, 013, 014, 017, 061	DE GRAAF	001, 004	GENERAL TECHNIC	013		KAMASONIC	014	MIYUKI	049
AURORA	014, 039, 061	DECCA	001, 014, 028, 036, 037, 056, 127, 150, 175, 197	GITEM	004		KANSAI	001, 013, 027	MORAVA	001, 045, 047, 068
AUSIND	006	DEGRAAF	001, 004	GM GMC	001, 013, 049, 052		KAPSCH	001, 003, 010, 013, 014, 035, 039, 043, 047, 073	MORAWA	001
AUTOVOX	004, 006, 008, 014, 035, 083, 108, 128	DEMA COLOR	006	GMG	013, 049, 052		KARCHER	001, 013, 014, 021, 073, 084, 134, 140	MOSAIC	001
AVA	001	DENON	105	GOLDSTAR	013, 014		KATHREIN	001, 009	MOTOROLA	268
AVEST	148, 164	DENVER	001, 013	GOLDSTAR	001, 002, 004, 006, 008, 013, 014, 021, 034, 043, 049, 063, 069, 077, 079, 086, 087, 121, 146		KAWA	070	MTC	001, 004, 021, 038, 136
AWA	001, 013, 061	DESMET	001, 003, 013, 016, 017, 021, 028	GOLDSTAR/LG	001, 008, 014, 021, 069, 086, 087, 121, 146		KAYA	013	MULTISYSTEMS	001
AXXENT	001	DINASTY	013	GOODMANS	001, 005, 009, 013, 014, 021, 036, 040, 061, 070, 149, 201		KENEDY	001, 008, 016, 019, 029, 034, 035, 043, 054, 083, 102, 131	MULTITECH	001, 004, 006, 008, 013, 014, 021, 023, 028, 029, 036, 037, 038, 040, 049, 061, 068, 084, 098, 143
AXXION	001, 013, 070	DIORA	236	GORENJE	001, 038, 040, 136, 140		KENNEX	001	MURPHY	003, 006
BAIHUA	040	DIXI	013, 090	GP	014		KERION	001	NAD	001, 030, 069
BAIRD	026, 056, 098	DOMOH	001	GPM	013, 040, 049, 063		KIMAY	049	NAGOYA	003
BANG&OLUFSEN	001, 016	DOMUS	003, 110	GRANADA	001, 003, 004, 005, 006, 010, 014, 020, 024, 027, 028, 030, 036, 042, 049, 051, 053, 057, 059, 096, 101, 110, 111		KITT	013, 014, 049	NAONIS	003
BARCO	016, 031	DORIC	001, 003, 004, 013, 014, 019, 021, 022, 034, 043, 050, 064, 078	GRANDIN	001, 003, 010, 017, 021, 040, 044, 084		KITTEN	001	NATIONAL	027
BARCOM	063	DUNAI	021	GREAT WALL	151		KLARMAX	003, 014, 021, 028, 073, 158	NEC	013, 017, 036, 037, 061, 063, 073, 107
BASIC LINE	001, 003, 004, 040, 057, 084	DUX	001	GRONIC	001, 014, 021, 023, 116, 158		KNEISSEL	001, 014, 054, 072, 116, 131	NECKERMANN	001, 002, 004, 007, 008, 009, 013, 014, 015, 016, 017, 022, 027, 028, 030, 034, 038, 048, 050, 054, 058, 060, 065, 140
BASIC LINE	001, 002, 003, 004, 007, 013, 022, 026, 030, 041, 050, 060	ECHO STAR	027	GRUNDIG	001, 002, 003, 004, 006, 009, 018, 092, 119, 120, 138, 153, 173, 228, 239		KOBIC	013	NEI	001, 003, 021, 040, 143
BAZIN	004, 008, 014	EDAN LINE	001	GTT	001, 013, 052, 084		KOENIG	009, 017, 029	NEPTUN	001, 089
BEKTEKNIK	038	ELBE	003, 006, 014, 021, 028, 034, 054, 072, 073, 131	GYTEM	001, 002, 004, 005, 011, 057		KOLON	021	NESCO	003, 008, 034, 219
BEKO	001, 005, 030, 038, 068, 153, 185	ELBE ELBIT	001, 003, 014, 021, 028, 034, 036, 054, 072, 073, 131, 134	HAIER	049, 053, 120, 164, 191, 261, 262, 263, 266, 267		KOLSTER	001, 008, 014, 021, 023, 040, 049, 073, 158	NEWMAR	003, 014, 021, 158
BEKOTEKNIK	038	ELBIT	001	HAISI	148, 214		KONKA	001, 040, 049, 052, 053, 070, 084, 187, 188, 191, 205, 215, 217, 218, 250, 254, 255, 256, 257, 264	NEWTECH	001, 014
BELSTAR	001	ELDORADO	001	HAMMERMANN	004, 014		KORTING	001, 016, 017, 038, 102, 136	NIKKAI	014, 030, 063, 079
BESTAR	009, 038	ELECTROVENDA	001	HAMPTON	014		KOTRON	021, 049	NIKKO	001, 143
BIAZET	001, 089	ELEKTA	001, 013, 049, 061, 084, 086	HANSEATIC	001, 003, 004, 013, 014, 017, 021, 022, 028, 029, 036, 040, 058, 060, 065, 068		KRAKING	021	NISHI	133
BIFONIC	013, 014	ELEKTRON	021	HANTAREX	001, 013, 028		KRONNE	014, 021	NOBLEX	013, 036, 061, 095, 125, 133, 157
BIG STONE	013, 049	ELEKTRONICA	014	HAPO	040		KUBA	004, 050	NOBLIKO	006, 008, 014, 023, 062
BLAUPUNKT	001, 002, 012, 015, 026, 027, 048, 092, 100, 120	ELEKTRONIKA	001, 140	HCM	001, 013, 014, 021, 049		KUBA ELECTRONIC	004, 050	NOGAMATIC	011, 018, 031
BLAUSONIC	014	ELEKTRONSKA	021, 028	HEXAM	021, 106		KYOTO	014, 021	NOKIA	001, 003, 004, 006, 010, 012, 013, 016, 021, 024, 026, 027, 035, 037, 038, 039, 042, 043, 047, 049, 051, 052, 053, 057, 060, 061, 084, 111, 122, 149, 172, 211, 271
BLUE SKY	009, 153	ELEKTRONSKA IND.	021, 028	HIFIVOX	011, 018, 031		LASAT	189		
BLUE STAR	003, 004, 008, 021	ELEKTROTECH	013	HIGASHI	014		LAVIS	003, 028, 047, 073, 116	NORDING	006
BLUESKY	153	ELEMIS	001, 068, 089	HINARI	001, 004, 013, 036, 037, 040, 049, 063, 078, 116, 149		LCE	001, 070, 168, 190, 194, 195	NORDMENDE	001, 002, 003, 004, 005, 011, 018, 019, 027, 029, 032, 037, 046, 065, 066

OCEANIC	001, 003, 004, 009, 010, 024, 026, 044, 051, 057, 060, 167	RECORD	073	SONY	001, 007, 036, 037, 041, 207	TRISTAR	040, 049
OCTAL	014	REDDER	073, 125	SOUND COLOR	001, 070	TRIUMPH	062, 063, 078
OKANO	001, 013, 038	REDIFFUSION	003, 110	SOUND&VISION	023	TRONIC	013, 014, 061
OMEGA	070	REDSON	089	SOUNDMASTER	013	TVT	068, 182
ONCEAS	008, 013, 014	REFLEX	009	SOWTECH	038	UHER	001, 006, 017, 023, 035, 043, 050, 114
ONCOMMAND	229	REGENTE	013	SPECTRA	001, 061	ULTRAVOX	001, 004, 008, 014, 016, 017, 023, 029, 057, 174
ONDIOLA	017	REKORD	001, 009, 054, 061, 119, 120, 148, 166	STANDARD	001, 008, 013, 014, 017, 040, 061	UNIC RADIO	003, 014, 021, 028, 038
ONWA	001, 040, 049, 070	REOC	051	STARLITE	001, 013	UNIMOR	001, 038, 068, 089
OPTA	013	REVOX	001	STARLUX	013	UNIVERSUM	001, 002, 003, 004, 006, 007, 008, 012, 013, 014, 021, 022, 036, 037, 039, 041, 042, 047, 048, 049, 062, 063, 065, 077, 095, 101, 108, 111, 142, 196
ORAVA	001, 013, 021, 159	REX	001, 003, 004, 005, 034, 035, 043, 054, 083, 131	STENWAY	040	UNIVOX	001, 003, 008, 016, 021, 057, 073
ORBITER	038	RFT	001, 003, 009, 016, 023, 040, 068, 090	STERN	003, 004, 034, 035, 043, 054	UNIWERSUM	042, 111, 122
ORION	001, 004, 009, 037, 040, 049, 058, 063, 065, 078, 086, 091, 107, 115, 118, 164, 177	RITAR	024	STRATO	049	UNK	001, 003, 056, 189
ORSOWE	028	RIZ	021	STVI	014, 021	URANYA	001, 006, 013, 017, 023, 028, 158
OSAKI	001, 049, 065	ROADSTAR	001, 013, 021, 040	STYLANDIA	013	UTAX	013, 014
OSIO	077	ROBERTS	149	SUNKAI	037, 058, 065, 118	V.S.M.	033
OTAKE	058, 065, 115, 118	ROBOTRON ELEC.	016, 090	SUNSTAR	001, 013	VANGUARD	004, 013, 014
OTAVA	001, 183, 220	ROSITA	013, 049	SUPERLA	021, 028	VECO	001, 013
OTF	001, 021	ROWA	013	SUPERTEC	001, 003, 004, 013, 040, 049	VECTRA	001
OTHER LINE	028	ROWSONIC	014, 036, 089	SUPERTECH	001, 003, 004, 013, 040, 049	VESTEL	001, 003, 142, 185
OTTO VERSAND	001, 002, 003, 004, 005, 007, 008, 009, 012, 013, 014, 017, 021, 022, 025, 026, 027, 029, 030, 036, 041, 050, 058, 059, 060, 063, 064, 065, 068, 070, 087, 091, 093, 098, 115	ROYAL	001, 013, 014, 021, 040, 049, 052, 084, 129, 156, 179, 206	SUPRA	001, 009, 013, 049, 061, 065, 069, 086, 157, 208	VEXA	001, 013, 014, 040, 084
OVP	001	ROYAL HCM	084	SYC LINE	013	VIDEOLOGIC	014, 040
PAEL	001, 014	ROYAL LUX	001, 129	SYDNEY	016, 028	VIDEOSAT	008
PALLADIUM	001, 038	ROYAL LUX	001, 129	SYRIUSZ	001, 089	VIDEOSYSTEM	001
PANAMA	001, 014, 049	ROYAL-LUX	156	TADISTAR	001, 052	VIDEOTON	003, 004, 008, 014, 019, 021, 052, 060, 073, 171, 273, 274
PANASONIC	002, 007, 010, 016, 021, 027, 059, 081, 130, 221	RUBIN	142	TAISHO	021	VIDICRON	001, 017
PANAVISION	049	RUWIDO	051	TALENT	002	VIDIKRON	001
PANAVOX	029	SABA	004, 005, 010, 011, 014, 016, 018, 019, 024, 028, 031, 033, 037, 046, 071, 098, 103, 113, 135, 154	TANAKI	013	VIDION	013
PANORAMA	014, 049, 145	SAINEL	003	TANDBERG	011, 016, 018, 028, 034, 045, 054, 065, 081, 088, 108	VISION	001, 017
PANORAMIC	011	SAISHO	004, 014, 021, 037, 040, 058, 065, 078, 115	TANDY	001, 004, 044	VISIONREX	028
PANTERA	061	SAKAI	014	TASHIKO	001, 014, 021, 036, 074, 101	VISIOREX	028
PATHE CINEMA	014, 017, 021, 028, 073, 106, 174	SAKIO	013, 049	TATUNG	001, 014, 021, 028, 036, 037, 056, 127, 150, 175, 197	VISTAR	004, 057
PATHE MARCONI	011, 014, 017, 018, 021, 031, 033, 073, 106, 113, 174	SALORA	001, 003, 004, 010, 014, 024, 026, 042, 051, 060, 077, 079, 111	TAURUS	021	VOXSON	003, 006, 016
PAUSA	013	SAMBERS	006, 023, 028, 062, 063, 073, 077, 078, 134, 158	TCL	001, 129, 148, 204, 216, 258, 259	WALKIE	043
PCE	149	SAMSUNG	001, 004, 008, 009, 013, 014, 038, 049, 056, 063, 076, 077, 078, 084, 120, 133, 137, 144, 157, 193, 223	TCM	001	WALTHAM	001, 003, 004, 008, 014, 019, 021, 052, 057, 060, 073, 089
PCM	001	SANDRA COLOR	014, 028	TEAC	014, 022	WATSON	001, 003, 012, 013, 017, 029, 040, 049, 078
PERSHIN	006, 106	SANSUI	001, 070	TEC	001, 003, 004, 008, 013, 014, 021, 034, 043, 061, 078, 272	WATT RADIO	001, 003, 004, 014, 023, 029, 038, 056, 073, 134
PHILARMONIC	014, 021	SANWA	026	TECCO	008, 011, 013, 014	WEGA COLOR	016, 036
PHILCO	001, 003, 006, 008, 012, 013, 016, 021, 029, 036, 038, 052, 116, 131	SANY	019	TECHLINE	023	WEGA VOX	003, 008, 013, 052
PHILHARMONIC	008, 014, 021	SANYO	008, 013, 014, 016, 026, 029, 036, 037, 038, 047, 056, 090, 095, 096, 097, 101, 116, 238	TECHNEMA	017	WELTBlick	001, 017
PHILIPS	001, 002, 004, 006, 009, 013, 014, 016, 019, 020, 028, 033, 034, 036, 038, 043, 050, 063, 112, 123, 152, 176, 178, 202, 210, 212, 222, 269	SATURN	148	TECHNICA	040	WELTBlich	001, 017
PHILIPS(F)	001, 020	SCHAUB LORENTZ	001, 003, 004, 010, 013, 026, 038, 040, 061	TECHNICS	027, 059	WESTA	089
PHOCUS	001	SCHNEIDER	001, 003, 004, 006, 008, 009, 013, 014, 019, 020, 021, 023, 029, 033, 034, 040, 043, 049, 050, 063, 064, 070, 078, 114, 155, 162, 196	TECHNISAT	001, 090	WESTON	003, 021
PHOENIX	001, 029	SCHNEIDER FRANCE	001, 009, 014, 020, 033, 043	TECNISON	001, 013, 014	WHARFEDALE	001
PHONOLA	001, 009, 014, 016, 020, 112, 123	SCOTT	001, 017	TEDELEX	013	WHITE WESTING	001, 003, 006, 013, 014, 017, 021, 023, 035, 036, 038, 043, 052, 062
PINNACLE	270	SEG	001, 003, 004, 006, 008, 013, 014, 021, 023, 040, 049, 063, 090, 142	TEINEL	001, 003	WINFAST	231
PIONEER	001, 003, 019, 163	SEI	156	TEKNANT	001, 013	WINSTON	001, 013, 040, 084
PLANTRON	003, 008, 013, 028, 029	SEI SINUDYNE	001, 004, 009, 016, 023, 029, 034, 040, 041, 054, 058, 065, 066, 078, 091, 115, 117, 118	TEKON	013	WINTERNITZ	001, 013, 061
PLAYSONIC	014, 016, 073	SEIKO	061	TELE TECH	008	WISI	004
POLKOLOR	004	SELECO	001, 003, 004, 005, 009, 010, 019, 034, 035, 036, 043, 054, 066, 083, 108, 131, 184, 230	TELEAVIA	011, 018, 019, 031, 033, 046, 113	WORLD TECH	001
POPPY	013	SENDAY	001	TELEFUNKEN	005, 008, 011, 012, 018, 019, 021, 031, 032, 046, 055, 066, 071, 080, 094, 098, 103, 132	XANTRAX	120
PORTLAND	001, 061	SENTRA	004, 030, 040	TELEOPTA	013	XCELLENT	001
PRANDONI PRINCE	003, 006, 008, 023, 028, 029, 114	SHARP	025, 036, 120, 125	TELEPAC	013	XONYCS	001
PRIMA	013, 014, 049, 063, 168	SHINTOM	001	TELERENT	001	XRYPTON	001
PRINCESS	013	SHINTOSHI	001	TELESTAR	001, 009, 052, 209	YAMAHA	001
PRINTZ	001, 004, 065, 079, 089	SHIVA	036	TELETECH	001, 008, 013	YOKO	001, 008, 011, 013, 014, 021, 040, 049, 061, 140
PRO VISION	001	SHIVAKI	001, 003, 013, 021, 049, 061, 069, 084, 086, 087, 120, 141, 142, 148, 166, 175, 179, 244, 245, 246	TELETON	004, 014, 035, 043, 083	YORK	040
PROFESSOR	001, 013, 129, 194, 195	SHORAI	065	TELEVIDEON	001, 006, 014, 017, 029, 114	ZAMPA	004
PROFEX	001, 003, 006, 013, 015, 021	SIAREM	016, 023, 028, 029, 037	TELEVISO	044	ZANUSSI	003, 010, 035, 083
PROFITRONIC	001, 003, 023	SICATEL	021, 073	TELEXA	023	ZOPPAS	003
PROGRESSON	013	SICE	002	TENNESSEE	001		
PROLINE	021, 056, 115	SIDEC	021	TENSAI	001, 008, 009, 013, 014, 017, 021, 023, 029, 039, 040, 047, 061, 063, 065, 070, 087, 134		
PROSONIC	001	SIEL	006	TENSON	013, 017		
PROTECH	001, 013, 068	SIEMENS	001, 002, 012, 015, 026, 048, 063, 095, 101, 200	TESLA	001, 009, 016, 021, 073, 140, 142, 153, 155, 159, 169, 224, 235		
PROVISION	009, 156	SIESTA	038, 068, 164	TETTRAN	017, 021		
PYE	001, 020	SILELIS	021	TEVION	001		
PYGMY	016	SILMA	001	THOMSON	001, 003, 004, 005, 006, 010, 011, 014, 017, 018, 019, 021, 028, 031, 033, 046, 066, 071, 073, 094, 098, 103, 106, 113, 119, 135, 174		
QUASAR	006, 023, 063, 077, 078	SILVA	013, 014, 036, 040, 049, 063	THORN	001, 002, 003, 004, 005, 006, 007, 009, 011, 013, 014, 019, 020, 021, 022, 024, 026, 027, 028, 030, 034, 036, 037, 039, 041, 042, 047, 049, 051, 053, 055, 056, 057, 066, 071, 073, 074, 075, 078, 080, 082, 093, 094, 095, 096, 098, 103, 111, 123, 132, 150		
QUELLE	001, 002, 003, 004, 005, 006, 007, 008, 009, 012, 013, 014, 015, 021, 022, 024, 026, 027, 030, 032, 034, 035, 036, 037, 038, 039, 041, 042, 043, 047, 048, 049, 051, 054, 056, 058, 059, 062, 063, 064, 065, 077, 078, 093, 095, 101, 108, 111, 115, 122, 140	SILVER	036, 040, 049, 065	THUNDERMAX	172		
RADIALVA	001	SINGER	001, 008, 013, 014, 016, 023, 028, 029, 044, 061, 131	TICSONIC	014		
RADIOLA	001, 009, 020, 033	SIREL	028	TOBO	013		
RADIOMARELLI	001, 004, 008, 013, 016, 023, 028, 029, 052	SKYTTRONIC	001, 013	TOGOSHI	036, 125		
RADIONETTE	003, 010, 039, 047	SLAVA	014	TOKAI	003		
RADIOTONE	001, 013, 049, 068	SMARAGD	119	TOMITA	014		
RADUGA	001	SOGERA	017	TOP VISION	021		
RAINFORD	001	SOLAVOX	003, 004, 079	TOSHIBA	006, 014, 022, 030, 036, 074, 101, 170		
RANK BUSH MURPHY	006	SOME MODELS	013, 233	TOWADA	021, 023		
RBM	003, 004, 006, 021, 054, 110	SONICX	001	TOYOSI	001		
RCM	097	SONIKO	014, 016, 026	TR.CONTINENTS	003, 028		
RCU	051	SONITRON	017	TRANSCONTINENTS	003, 028		
REALISTIC	047	SONNECLAIR	001	TRANSONIC	001		
RECOR	001, 052	SONOKO	001, 013, 014, 040, 049, 084	TREVI	013, 040, 084		
		SONOLOR	003, 004, 010, 024, 044, 057	TRILUX	001, 068, 210		
		SONTEC	001, 008, 013, 038, 049				